

RE-INKING: PRE-INKED STAMPS

1/ ESSENTIAL: USE THE CORRECT INK!

USE 'RE-INKING FLUID' **ONLY**. DO **NOT** USE 'REGULAR' STAMP INK OR SIMILAR. IF IN DOUBT, CALL US! ADVICE IS FREE! YOU MUST USE THE SAME COLOR INK AS THE ORIGINAL STAMP – YOU **CANNOT** CHANGE COLOR!

2/ (A) SEE IF THE STAMP HANDLE IS REMOVABLE. IF IT IS, DO SO, AND SQUEEZE A FAIRLY SMALL QUANTITY OF INK INTO THE TUBE(S) PROVIDED.

(B) IF HANDLE IS NOT REMOVABLE, TURN THE STAMP UPSIDE DOWN, AND REMOVE THE BASE PLATE (IF ONE IS PROVIDED). THE PRINTING PART OF THE STAMP SHOULD NOW BE EXPOSED.


3/ SQUEEZE RE-INKING FLUID SPARINGLY OVER THE RAISED CHARACTERS ONLY. LET THE STAMP SIT IN THIS UPSIDE DOWN POSITION FOR **AT LEAST 12 HOURS**, SO THAT THE FLUID IS PROPERLY ABSORBED INTO THE STAMP DIE.

4/ CAUTIONARY NOTE

MOST – BUT NOT ALL – PRE-INK STAMPS CAN BE RE-INKED. THE AGE OF THE STAMP AND/ OR ITS DESIGN CAN AFFECT THIS PROCEDURE. IF RE-INKING DOESN'T WORK THE FIRST TIME, TRY AGAIN. IF IT STILL DOESN'T WORK, YOU NEED A NEW STAMP.



RE-INKING: MaxLight PRE-INKED STAMPS

PRE-INKED STAMPS Re-Inking Instructions



How to re-ink your pre-inked stamp:

- Remove the handle and place the required amount of MaxLight™ ink in the ink ports. Sizes do vary, so the amount of ink is determined by the size/model number. Divide the quantity of drops between the two ink ports. For ink amounts, refer to back side of this sheet. Let the stamp sit overnight. If the impression is still too light, repeat.
- Always re-ink with the same color of the original stamp.
- Leave stamp in upright position after inking.



For best results, use MaxLight™ Ink only. Other types of ink may damage your stamp.

Re-inking a pre-inked inspector stamp:

- Remove handle & apply 3-4 drops of same color ink in the back of the stamp.
- Leave stamp in upright position after inking.
- Repeat if necessary.



Other points to consider about your pre-inked stamp:

- The type of paper the impression is made on will determine its drying time. Your stamp is not intended for use with glossy paper.
- The dust cover allows you to keep your stamp clean when not in use. If the surface of the stamp does get dirty, place cellophane tape directly on the stamp surface and remove. The tape will remove loose particles and enable the stamp to make better impressions.
- If you get ink on your fingers, use rubbing alcohol and then soap and water.
- To avoid stains, keep away from clothing.
- Keep your pre-ink stamp away from children.

PRE-INK SIZES & INK QUANTITIES:

Sizes 55, 75, 325, 305 = **3-4 Drops**

Sizes 115, 125, 145 = **4-6 Drops**

Sizes 185, 265 = **6-8 Drops**

Sizes 165, 535 = **8-10 Drops**

Size 245 = **10-12 Drops**

Size 225 = **12-14 Drops**

Size 275 = **15-20 Drops**

Size 700 = **20-24 Drops**

IMPORTANT NOTE: Divide the quantity of drops between the 2 ink ports.